

3 Tier Step for Cold Plunge Installation Instructions



Place the top step of the hot tub steps (curved at the back) upside down and place 1 side of the stairs inside the lip of the side and front of step.

Fasten with 2 2 ½" (64mm) screws.

Repeat on opposite side.



Repeat for the bottom and middle step.



Flip the assembled steps over and place where desired against Cold Plunge tub.

Manufactured by:

