

FAQ for a flaptack assembly

1. The door including the frame looks too tall. Is this correct?

This usually happens because the temporary bottom board/strip has not been removed. As shown in the assembly manual, this board must be removed before installing the door. Once removed, the door frame will be at the correct height.

2. Which side of the floor panel should face upwards?

The film-coated (smooth, mirror-like) side of the floor panel must face upwards. The green side should be on top, the black side facing downwards.

3. Where should the coating from the can be applied?

The coating must be applied to the top side of the floor structure only.

4. What does “apply a hydroisolation layer” mean?

First, apply Hydrotape to the joints and base. Then apply the hydroisolation oil supplied in the grey can. This process prevents water from penetrating into the wooden boards.

5. What is the purpose of “Hydrotape”?

Hydrotape G is used to waterproof the joints between floor panels. First, apply the waterproofing layer to the joints, then place Hydrotape on top. After that, cover the entire floor with the grey waterproofing coating.

6. How should the floor drain be prepared?

Please drill a hole with a diameter of 54 mm in the floor. Then install the siphon included in the package.

7. Can the door side be changed?

Yes, in this case the OSB panel must be turned to the opposite side and then fixed in place.

8. What should be considered when assembling OSB panels?

Do not screw too close to the edge of the panel and avoid overtightening the screws. Screws should be at least 10 mm away from the edge of the board to prevent cracking.

9. What is the required height between the upper bench and the ceiling?

The distance from the top point of the upper bench to the ceiling is 1.10 m.

10. Do roof profiles need to be cut?

Yes, in some cases roof profiles must be trimmed. This should only be done after the exterior cladding is installed, so the profiles can be cut precisely to the required length for a perfect fit.

11. How should interior boards be installed – tongue or groove facing upwards?

The groove must face downwards and the tongue must face upwards.

12. Do some boards really need to be cut to size as shown in the assembly manual?

Yes. Certain boards must be cut to the specified dimensions exactly as indicated in the assembly manual.

13. Where are the profiles that cover the front near the glass packed?

These profiles are packed together with the glass frame as one unit. They are not supplied separately.

14. Is cable routing pre-installed?

No. Cable routing must be prepared before starting the exterior and interior cladding. Drillings or grooves for cables are not pre-made.

15. Should the edge trims really be mounted before the outer cladding?

Yes. The edge trims must be installed first. The final cladding board should then be cut on the groove side and fitted into place without removing the edge trim.

16. Where is Soudal Silirub 2 used?

Soudal Silirub 2 is a sealant. It is applied to the window frame where the glass is installed and around the roof perimeter near the edge of the bitumen coating. This ensures protection against water penetration.

17. How is the roof covering installed?

The installation method depends on the type of roof covering used.

If a **bitumen roof covering** is used, it is heat-welded (torch or fan-applied) to the surface and must not be fixed with nails or screws.

If an **EPDM membrane** is used, it is installed by fully bonding it to the roof surface using only an adhesive.