

Meridian Shower Installation Instructions

Congratulations on your purchase of a Meridian outdoor shower! Your shower is easy to install and operate.

Tools Needed for Assembly: • Cordless drill • Pliers • Level

Mounting: First attach the 2 mounting brackets to the rear of the shower with four screws, then mount your Meridian shower to any vertical surface using the eight screws included in your kit.

Operation

Once mounted you can “plumb” your shower in two ways, either using a garden hose from a nearby faucet or plumbing with hot and cold water as with fixtures in your home.

- For use with a garden hose, attach the two ends of the hose splitter to the inlets on the back of the shower. Be sure rubber gasket is in place and then gently tighten with a pliers. Next, being sure rubber gaskets are in place, attach your garden use to the single port of the hose splitter with the swivel adaptor and gently tighten.
- To use hot and cold water you can either run another garden hose to the second inlet or consult a plumber for the best way to bring water to the shower.
- If you find any drips or leaks in any of the fittings, simply locate the source and tighten the fitting with a wrench. Be sure to check that the rubber seal is properly in place and thread tape is used before re-tightening any fittings.

In the Months and Years Ahead...

- We use red cedar for your shower because red cedar is naturally resistant to the effects of weather and moisture. Over time you will see the red cedar turn a silvery-gray as a result of UV exposure. This in no way hurts the lumber, and the natural weathering of the wood adds charm to the shower over time. If you wish to retain the original color of the wood and minimize the effects of UV, you can stain the lumber with a UV-inhibited stain of your choice.
- To clean the wood or bring back the original color you can use a pressure washer in the same way you would clean a wooden deck. Be sure to use a wide pattern and keep a distance from the wood as it is easy to damage the soft cedar with too much pressure.
- Fully drain the shower and remove wand, hose and showhead fixture in freezing temperatures.




1. Attach mounting brackets.



2. Thread shower head onto stem and gently tighten with wrench.



3. Thread hose onto valve assembly as shown and gently tighten with wrench.



4. Thread other end of hose to hand wand.